



## **CORNER ROD WITH TWO SUPPORTS** **INSTALLATION INSTRUCTIONS**

### **SHOWER ROD CONTENT**

- (3) Rods
- (2) Insert
- (2) Brackets
- (8) Mounting Screws
- (8) Anchors
- (2) Set Screws

### **CEILING SUPPORT CONTENT**

- (2) Support Rod
- (2) O-loop
- (2) Bracket
- (4) Mounting Screws
- (4) Anchors
- (4) Set Screws

### **INSTALLATION**

1. Hold flanges to the wall and mark location of screw holes to be drilled.
2. Assemble the three lengths of rod by putting together with the splice.
3. Slide ceiling support from both end at this time.
4. Insert tubing into both end flanges. Tighten into place with the set screws.
5. Slide rod into place on wall. Insert screws and fasten.

**Rod can easily be trimmed down to a shorter length on site**

